

CONVERTING YOUR MIRROR TO CENTRE SHEETING

Parts you will need

- 1x mainsheet pulley (fixed style pulley for attaching to bridal rope on transom)
- 1x pulley (swivelling **with becket**)
- 1x ratchet block (**use existing** from transom)
- 1x pulley (**use existing** mainsheet pulley from end of boom)
- 1x mainsheet (new longer mainsheet required)
- 1.5m of 4mm bridal rope (tie off to give 275mm peak above transom)
- 2x saddles to tie bridal rope to transom
- 1x strop (for fixing to middle of alloy booms – use a saddle instead if you have a wooden boom)

SAILING TIP: Once you have made the change be careful. Do not over sheet, which is really easy to do with centre sheeting - watch the telltales on your leech and ensure they are streaming.

